

32 - 5001
MANUAL
of Operating & Maintenance
Procedures
for

Series 2000
Digital Multimeter
Model 2500

 **DATA PRECISION**
... years ahead

AUDUBON ROAD, WAKEFIELD, MASSACHUSETTS

A1 OPTION SUPPLEMENT
INSERTED AT REAR OF
MANUAL

*option
A1
A3
A4*



Frontispiece. SERIES 2000 DMM Model 2500

CONTENTS

Section Para.	Title	Page	Section Para.	Title	Page
1.	INTRODUCTION	1-1	4.	PRINCIPLES OF OPERATION	4-1
	Specifications Model 2500	1-2	4.1	General	4-1
	Specifications Model 2400	1-4	4.2	System Block Diagram	4-1
2.	OPERATION	2-1	4.3	Signal Conditioning Block	4-3
2.1	Unpacking	2-1	4.4	Tri-Phasic A/D Converter Block	4-4
2.2	Operating Controls and Indicators	2-1	4.5	Trigger Generator and Clock	4-4
2.3	Power Connections	2-1	4.6	Decade Counter Chain, Latch, and Decoder	4-5
2.4	Guard Connections	2-1	4.7	Ranging	4-5
2.5	Ranging	2-5	4.8	Power Supply Block	4-5
2.6	Zeroing	2-5	4.9	Detailed Operation	4-5
2.7	Voltage Measurements	2-5	4.10	Signal Conditioning Details	4-7
2.8	Voltage Ratio Measurements	2-6	4.11	Ratiohm Resistance Input Conditioning Details	4-9
2.9	Resistance Measurements	2-6	4.12	A/D Converter Details	4-10
2.10	Remote Control/Operation	2-7	4.13	Trigger Generator and Counter	4-12
3.	CALIBRATION	3-1	4.14	Ranging	4-14
3.1	Calibration Verification	3-1	5.	OPERATOR & FIELD MAINTENANCE	5-1
3.2	Preliminary Set Up Conditions	3-1	5.1	General	5-1
3.3	Calibrating Equipment	3-1	5.2	Parts Grouping and The Test Stand-Offs	5-1
3.4	Access to Calibration Adjustemnts	3-1	5.3	The Troubleshooting Flow Chart	5-3
3.5	Calibrating Sequence	3-1	5.4	Using the Troubleshooting Flow Chart	5-3
3.6	DC Voltage Measurement Mode	3-3	6.	REFERENCE MATERIALS	6-1
3.7	Resistance Measurement Mode	3-3		Parts Lists	
3.8	AC Voltage Measurement Mode	3-3		Reference Schematics	
3.9	Ratio DC Voltage Measurement Mode	3-4			
3.10	Post-Calibration	3-4			